

Cat. No. HO69-E1-2

ES100P

Digital Controller

USER MANUAL

OMRON®

Certain Terms and Conditions of Sale

- Offer; Acceptance.** These terms and conditions (these "Terms") are deemed part of all catalogs, manuals or other documents, whether electronic or in writing, relating to the sale of goods or services (collectively, the "Goods") by Omron Electronics LLC and its subsidiary companies ("Seller"). Seller hereby objects to any terms or conditions proposed in Buyer's purchase order or other documents which are inconsistent with, or in addition to, these Terms. Please contact your Omron representative to confirm any additional terms for sales from your Omron company.
- Prices.** All prices stated are current, subject to change without notice by Seller. Buyer agrees to pay the price in effect at time of shipment.
- Discounts.** Cash discounts, if any, will apply only on the net amount of invoices sent to Buyer after deducting transportation charges, taxes and duties, and will be allowed only if (i) the invoice is paid according to Seller's payment terms and (ii) Buyer has no past due amounts owing to Seller.
- Orders.** Seller will accept no order less than \$200 net billing.
- Governmental Approvals.** Buyer shall be responsible for, and shall bear all costs involved in, obtaining any government approvals required for the importation or sale of the Goods.
- Taxes.** All taxes, duties and other governmental charges (other than general real property and income taxes), including any interest or penalties thereon, imposed directly or indirectly on Seller or required to be collected directly or indirectly by Seller for the manufacture, production, sale, delivery, importation, consumption or use of the Goods sold hereunder (including customs duties and sales, excise, use, turnover and license taxes) shall be charged to and remitted by Buyer to Seller.
- Financial.** If the financial position of Buyer at any time becomes unsatisfactory to Seller, Seller reserves the right to stop shipments or require satisfactory security or payment in advance. If Buyer fails to make payment or otherwise comply with these Terms or any related agreement, Seller may (without liability and in addition to other remedies) cancel any unshipped portion of Goods sold hereunder and stop any Goods in transit until Buyer pays all amounts, including amounts payable hereunder, whether or not then due, which are owing to it by Buyer. Buyer shall in any event remain liable for all unpaid accounts.
- Cancellation; Etc.** Orders are not subject to rescheduling or cancellation unless Buyer indemnifies Seller fully against all costs or expenses arising in connection therewith.
- Force Majeure.** Seller shall not be liable for any delay or failure in delivery resulting from causes beyond its control, including earthquakes, fires, floods, strikes or other labor disputes, shortage of labor or materials, accidents to machinery, acts of sabotage, riots, delay in or lack of transportation or the requirements of any government authority.
- Shipping; Delivery.** Unless otherwise expressly agreed in writing by Seller:
 - Shipments shall be by a carrier selected by Seller;
 - Such carrier shall act as the agent of Buyer and delivery to such carrier shall constitute delivery to Buyer;
 - All sales and shipments of Goods shall be FOB shipping point (unless otherwise stated in writing by Seller), at which point title to and all risk of loss of the Goods shall pass from Seller to Buyer, provided that Seller shall retain a security interest in the Goods until the full purchase price is paid by Buyer;
 - Delivery and shipping dates are estimates only.
 - Seller will package Goods as it deems proper for protection against normal handling and extra charges apply to special conditions.
- Claims.** Any claim by Buyer against Seller for shortage or damage to the Goods occurring before delivery to the carrier must be presented in writing to Seller within 30 days of receipt of shipment and include the original transportation bill signed by the carrier noting that the carrier received the Goods from Seller in the condition claimed.
- Warranties.** (a) **Exclusive Warranty.** Seller's exclusive warranty is that the Goods will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Seller (or such other period expressed in writing by Seller). Seller disclaims all other warranties, express or implied. (b) **Limitations.** SELLER MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE GOODS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE GOODS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. Seller further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Goods or otherwise of any intellectual property right. (c) **Buyer Remedy.** Seller's sole obligation hereunder shall be to replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Good or, at Seller's election, to repay or credit Buyer an amount equal to the purchase price of the Good; provided that in no event shall Seller be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Goods unless Seller's analysis confirms that the Goods were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any goods by Buyer must be approved in writing by Seller before shipment. Seller shall not be liable for the suitability or unsuitability or the results from the use of Goods in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.
- Damage Limits; Etc.** SELLER SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE GOODS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Seller exceed the individual price of the Good on which liability is asserted.
- Indemnities.** Buyer shall indemnify and hold harmless Seller, its affiliates and its employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim, investigation, litigation or proceeding (whether or not Seller is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Goods. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless Seller and defend or settle any action brought against Seller to the extent that it is based on a claim that any Good made to Buyer specifications infringed intellectual property rights of another party.
- Property; Confidentiality.** The intellectual property embodied in the Goods is the exclusive property of Seller and its affiliates and Buyer shall not attempt to duplicate it in any way without the written permission of Seller. Notwithstanding any charges to Buyer for engineering or tooling, all engineering and tooling shall remain the exclusive property of Seller. All information and materials supplied by Seller to Buyer relating to the Goods are confidential and proprietary, and Buyer shall limit distribution thereof to its trusted employees and strictly prevent disclosure to any third party.
- Miscellaneous.** (a) **Waiver.** No failure or delay by Seller in exercising any right and no course of dealing between Buyer and Seller shall operate as a waiver of rights by Seller. (b) **Assignment.** Buyer may not assign its rights hereunder without Seller's written consent. (c) **Amendment.** These Terms constitute the entire agreement between Buyer and Seller relating to the Goods, and no provision may be changed or waived unless in writing signed by the parties. (d) **Severability.** If any provision hereof is rendered ineffective or invalid, such provision shall not invalidate any other provision. (e) **Setoff.** Buyer shall have no right to set off any amounts against the amount owing in respect of this invoice. (f) As used herein, "including" means "including without limitation".

Certain Precautions on Specifications and Use

- Suitability of Use.** Seller shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Good in the Buyer's application or use of the Good. At Buyer's request, Seller will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Good. This information by itself is not sufficient for a complete determination of the suitability of the Good in combination with the end product, machine, system, or other application or use. The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of this Good, nor is it intended to imply that the uses listed may be suitable for this Good:
 - Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
 - Energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
 - Systems, machines and equipment that could present a risk to life or property. Please know and observe all prohibitions of use applicable to this Good.
- Programmable Products.** Seller shall not be responsible for the user's programming of a programmable Good, or any consequence thereof.
- Performance Data.** Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Seller's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Seller's Warranty and Limitations of Liability.
- Change in Specifications.** Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Good may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Seller's representative at any time to confirm actual specifications of purchased Good.
- Errors and Omissions.** The information in this catalog has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors, or omissions.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE SELLER'S PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Preface

Thank you for your purchase of your ES100. This digital controller has been achieved as a result of three development concepts:

- Friendly
- Intelligent
- User-oriented

This User's Manual has been designed specifically for the ES100P programmable type ES100, and explains its features and mode of use.

Before using your ES100P, thoroughly read and understand this manual in order to ensure correct use.

Caution

© OMRON, 1994

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein.

Moreover, because OMRON is constantly striving to improve its high-quality products, the information in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

How to Read this Manual

■ ES100P manuals

A total of three manuals are provided for the ES100P series digital controller as follows:

- When using the general features of the ES100P series digital controller:

ES100P Digital Controller
User's Manual (Cat. No. H069-E1-2)

- When using the communications features:

ES100 Digital Controller
User's Manual (Communications Guide) (Cat. No. H072-E1-2)

- When using the support software:

ES100 Support Software
ES/TOOLS Support Software
User's Manual (Cat. No. H071-E1-1)

■ The meaning of icons used in this manual

Icons are used in this manual in addition to explanatory text. Icons are used in order to visually represent information and facilitate understanding as you read through this manual. The three icons shown below are used throughout this manual. However, you will find some icons specific to certain chapters of the manual. For details on these icons, read the explanation at the beginning of the relevant chapter. The following icons are used throughout this manual, and mean the following:




“Caution” mark

This mark indicates that the caution that follows must be heeded at all times.



“Reference” mark

This mark indicates that extra, useful information follows, such as supplementary explanations and how to apply functions.



“See” mark

This mark indicates that you can refer to additional information relating to the preceding explanation.

■ How this Manual is Organized

Purpose	Title	Description
● Learning about the general features of the ES100P	Chapter 1 What is the ES100P?	This chapter describes the features of the ES100P, names of parts, and typical functions.
● Setting up the ES100P	Chapter 2 Preparations	This chapter describes the operations that you must carry out (e.g. installation, wiring and switch settings) before you can use the ES100P.
● ES100P operations	Chapter 3 Basic Operation	This chapter describes how to use the front panel keys and how to view the display when setting the parameters of the major functions of the ES100P.
● How to use parameters	Chapter 3 Basic Operation Chapter 4 Applied Operation Chapter 5 Parameters	Chapter 4 describes more advanced ways of utilizing the major functions described in Chapter 3. Chapter 5 describes in detail the parameters related to these functions when setting parameters.
● Learning about control using on the ES100P	Chapter 6 Typical Examples	This chapter gives typical examples of control that can be achieved on the ES100P, and the key points to remember in each of the control methods.
● Troubleshooting	Chapter 7 Troubleshooting	This chapter describes what to do if any problems occur.

Caution in Installing this Controller

- When connecting input or output lines to your controller, keep the following points in mind to reduce the influence from external noise: Avoid parallel or common wiring with high voltage sources and power lines carrying large currents. Allow adequate space between the high voltage/current lines and the input/output lines. Using separating pipes, duct work, and line shields is also useful in protecting the controller and its lines from external noise.
- Allow as much space as possible between the controller (including input/output cables) and devices that generate a powerful, high frequency (high-frequency welders, high-frequency sewing machines, and so forth). These devices may cause power surges and other malfunctions.
- If there is a large power-generating device near the controller and any of its lines, attach a surface absorber or noise filter to the device to stop the noise from affecting the controller system. In particular, motors, transformers, solenoids, and magnetic coils have an inductance component, and therefore can generate very strong noises.
- When mounting a noise filter, be sure to first check the filter's voltage and current capacity, then mount the filter as close as possible to the controller. You can also sometimes improve the controller's resistance to noise by grounding the controller to the control board.
- To reduce radiation noise and the influence of radiation noise, be sure to ground the control board. Also, be sure to ground the FG terminal of the external power supply.
- Do not use the controller in places where icing, condensation, dust, corrosive gas (especially sulfide gas or ammonia gas), shock, vibration, splashing liquid, or oil atmosphere occur. Also, avoid places where the controller can be subjected to intense heat radiation (like from a furnace) or sudden temperature changes.
- Ambient temperature must be kept between -10°C to 55°C . Ambient humidity must be kept between 35%RH to 85%RH (with no ice or condensation). If the controller is installed inside a control board, the ambient temperature must be kept under 55°C , including the temperature inside the control board. If the controller is subjected to heat radiation, use a fan to cool the surface of the controller to under 55°C .
- Store the controller at an ambient temperature between -25°C to 65°C . The ambient humidity must be between 35%RH to 85%RH (with no ice or condensation).
- Never place heavy objects on, or apply pressure to the controller that may cause it to deform during use or storage.
- Avoid using the controller in places near a radio, television set, or wireless installation—these devices can cause radio disturbances which adversely affect the performance of the controller.
- Use a stable voltage (100 to 240 V AC at 50 to 60 Hz). At power ON, the prescribed voltage level must be attained within two seconds.
- If you remove the controller from its case, never touch the electronic parts inside, nor allow static or any other kind of electrical source to contact the controller components.

Table of Contents

CHAPTER 1 WHAT IS THE ES100P? -----	1-1
This chapter introduces the ES100P. First-time users should read this chapter without fail.	
1-1 Features -----	1-2
1-2 Names of Parts -----	1-3
1-3 Input and Output -----	1-6
1-4 Parameters and Setting Levels -----	1-8
1-5 SP Mode -----	1-9
1-6 Operation Assignment Function -----	1-10
1-7 Fine Tuning -----	1-12
CHAPTER 2 PREPARATIONS -----	2-1
This chapter describes the operations you should carry out before turning the ES100P ON.	
2-1 Installing the ES100P -----	2-2
2-2 Setting the Switches -----	2-4
2-3 Wiring Terminals -----	2-5
2-4 Wiring Expanded I/O Connectors -----	2-8
CHAPTER 3 BASIC OPERATION -----	3-1
This chapter describes the most important operations of the ES100P.	
3-1 Operation Flow -----	3-2
3-2 How to Use the Panel Keys -----	3-3
3-3 Setting I/O Specifications -----	3-4
3-4 Key Display and Assignments -----	3-7
3-5 Setting Events -----	3-9
3-6 Setting up Programs -----	3-13
3-7 Starting and Stopping Operation -----	3-21
3-8 Adjusting Control Operation -----	3-22

CHAPTER 4 APPLIED OPERATION ----- 4-1

This chapter describes operations required for making full use of the features of the ES100P.

4-1	ON/OFF Timer -----	4-2
4-2	Digital Operation Assignments -----	4-4
4-3	Analog Operation Assignments -----	4-7
4-4	Mixed Analog/Digital Operation -----	4-12
4-5	PID Switching -----	4-13
4-6	Applying Programmed Operation -----	4-15
4-7	Changing the SP Mode -----	4-21
4-8	Checking Data -----	4-22

CHAPTER 5 PARAMETERS ----- 5-1

This chapter describes the parameters of the ES100P.
Use this chapter as a reference guide.

[Setting Level 2]

5-1	Specification Setting Mode -----	5-3
5-2	Event Setting Mode -----	5-25
5-3	ON/OFF Timer Setting Mode -----	5-28
5-4	Digital Operation Assignment Setting Mode -----	5-31
5-5	Analog Operation Assignment Setting Mode -----	5-36
5-6	Setting Level 2 Technical Mode -----	5-42

[Setting Level 1]

5-7	Manual Mode Parameter Setting Mode -----	5-52
5-8	Operation Mode -----	5-53
5-9	Tuning Mode -----	5-60
5-10	Program Setting Mode -----	5-62
5-11	PID Control Parameter Mode -----	5-70
5-12	Adjustment Mode -----	5-74
5-13	Check Mode -----	5-82
5-14	Setting Level 1 Technical Mode -----	5-90

CHAPTER 6 TYPICAL EXAMPLES -----	6-1	
This chapter describes examples of control by one ES100P.		
6-1 Heating/Cooling Control -----	6-2	
6-2 Position-proportional Control -----	6-5	
6-3 Cascade Control -----	6-8	
6-4 Feed-forward Control -----	6-11	CHAPTER 1
 CHAPTER 7 TROUBLESHOOTING -----	 7-1	
This chapter describes how to find out and remedy the cause if the ES100P does not function properly.		
7-1 Initial Checks -----	7-3	CHAPTER 2
7-2 How to Use the Error Display -----	7-4	
7-3 Judging Symptoms to Find the Cause of Trouble -----	7-7	CHAPTER 3
 APPENDICES		
SPECIFICATIONS -----	A-2	CHAPTER 4
HOW TO USE THE CURRENT DETECTOR (CT) -----	A-5	
CONTROL BLOCK DIAGRAM -----	A-8	
HOW TO READ DISPLAY SYMBOLS -----	A-9	CHAPTER 5
CONTROL OPERATION CYCLE -----	A-10	
PARAMETER LIST -----	A-11	
OPERATION ASSIGNMENT TABLE DEFAULTS -----	A-18	CHAPTER 6
MODEL LIST -----	A-20	
PROGRAM SETTING TABLES -----	A-21	
 INDEX		CHAPTER 7
 PARAMETERS & OPERATION PROCEDURE		APPENDICES

CHAPTER 1

WHAT IS THE ES100P?

1.1 Features -----	1-2
1.2 Names of Parts -----	1-3
Main parts-----	1-3
Front panel-----	1-4
Front panel (inside cover) -----	1-5
1.3 Input and Output -----	1-6
Layout of I/O terminals -----	1-6
Input -----	1-6
Output -----	1-7
1.4 Parameters and Setting Levels ---	1-8
1.5 SP Mode -----	1-9
1.6 Operation Assignment Function -	1-10
What is an	
“operation assignment”? -----	1-10
Digital operation assignments ----	1-11
Analog operation assignments ---	1-11
Mixed analog/digital operation --	1-11
1.7 Fine Tuning -----	1-12

1.1 Features

● *Easy Operation*

- You can easily set and adjust parameter settings using the support software (*1).
- You can quickly set operating instructions or frequently used parameters using programmable function keys.
- You can easily make optimum adjustments to control using the auto-tuning and fine tuning functions.

● *Almost All Types of Control are Possible on a Single Unit.*

- Control is facilitated by using the parameters provided exclusively for heating-cooling control.
- You can choose between floating and closed control on a position-proportional control system.
- Control is facilitated by using the cascade control parameters on a 2-input controller. Operation assignment functions are also supported for ratio control and feed-forward control.

● *A Wide Range of I/O Functions*

- Two inputs are available for analog input: analog input 1 and analog input 2. You can choose from thermocouple, platinum resistance thermometer, current input and voltage input for analog input 1. You can choose from current input and voltage input for analog input 2.
- Two control outputs and one transfer output are available for analog output. Control outputs are configured in modules so that you can choose the electrical interface matched to the control target.
- A maximum of eight digital inputs and ten digital outputs are provided.
- Two communications functions are available: serial communications and BCD communications. (*2)

● *I/O Functions Can be Re-assigned*

- Digital and analog I/O are not fixed; you can use the digital operation assignment and analog operation assignment functions to assign the optimum I/O functions to the desired control target.
- Digital I/O signals can be assigned by the digital operation assignment function.
- You can use the analog operation assignment function to process data to achieve control operation for analog input. You can also use the analog operation assignment function to process control operation in order to output the control operation results as analog output.

● *Enhanced Programming Functions*

- You can set up to 99 program patterns consisting of up to 100 steps (a maximum of 400 steps) in a single pattern.
- You can not only use the pattern by switching, but can also run the same programs using the repeat function and linking patterns together.

*1 ES/TOOLS Support Software is sold separately.

*2 See the ES100 Digital Controller User's Manual, Communications Guide.


1.2 Names of Parts

■ Main parts


The figure below shows the main parts of the ES100P, and describes each of their functions.

For more details on these main parts, see the page numbers for each description.

CHAPTER 1



■ Front panel



No.1 display

Displays parameter symbols when setting parameters. During setting of parameters, the PV and SP LEDs do not light.

Displays the process value (PV) or the set point (SP) during monitoring. Either of the PV or SP LEDs lights according to the display content.

No.2 display

Displays settings when setting parameters. During setting of parameters, the SP and MV LEDs do not light.

Displays the process value (PV), elapsed time and the manipulated variable (MV) during monitoring. One of the SP or MV LEDs lights according to the display content.

Bar graph

This bar graph indicates the manipulated variable, valve opening position, elapsed-time%, and deviation. The user can designate in parameters which items are displayed on the bar graph.

Output indicators

The corresponding LEDs lights depending on which control outputs (OUT1, OUT2) and auxiliary outputs (SUB1, SUB2) are ON.

Operation status indicators 1

These indicators display the operation status.

RUN lights when the program is running.

HOLD lights when the program is in hold status.

RST lights when the control is in reset status.

Operation status indicators 2

These indicators display the current control status.

- RMT LED : Lights when the current mode is set to remote or external.

- FSP LED : Lights when the SP mode is set to a fixed value.

- AT LED : Flashes when auto-tuning is being executed.

- WAIT LED : Lights when the program is in wait status, and flashes when a wait alarm occurs.




- MAN LED : Lights when the current mode is the manual mode.

Program No. display

When setting and running the program, the PTN display indicates the pattern No. and the STEP display indicates the step No. When setting table parameters, the STEP display indicates the table No.

LSP status indicators

These indicators display the status of the local SP during execution of the program for the currently executing step.

-  : Lights when the running program step is ramp up.
-  : Lights when the running program step is soak.
-  : Lights when the running program step is ramp down.

Front panel keys


The **PF1** and **PF2** keys are programmable function keys. The user can assign functions to these keys.

The **PTN** key advances patterns.

The **RUN** key starts execution of a program.

■ Front panel (inside cover)

CHAPTER 1

**Setting level 1 mode indicators**





The LED corresponding to the mode set in setting level 1 lights. Correspondence between the LED and setting mode is as follows:

- OPR LED : Operation mode
- TUNE LED : Tuning mode
- PRGM LED : Program setting mode
- PID LED : PID set setting mode
- ADJ LED : Adjustment mode
- CHECK LED: Check mode



Set key

Designates the first parameter in each setting mode.

Shift keys

- Pressing the  key designates the next parameter.
- Pressing the  key designates the previous parameter.
- Pressing the  key designates the next table No.
- Pressing the  key designates the previous table No.

Up/Down keys

Each press of the  key increments values by 1, and each press of the  key decrements values by 1. The display remains dim until the **ENT** key is pressed.

Enter key

This key is used to enter a setting. When pressed, the dim display changes to a lit display.

Edit key

This key is used for editing programs.

Auto/Manual key

Each press of this key switches between auto and manual modes.


RS-232C jack

This RS-232C interface jack is for communicating with the ES/TOOLS support software (sold separately). Cables other than the dedicated cable (sold separately) cannot be used with the ES/Tools support software.

1.3 Input and Output

Layout of I/O terminals

The ES100P rear panel is provided with terminals and expanded I/O connectors. Input and output terminals are arranged in groups as shown in the figure below. The rear panel can be configured in a variety of ways depending on the model you have purchased.



Input

- Analog input 1
- Analog input 2
- CT input
- Potentiometer input
- Auxiliary input (digital input)

- A total of 26 analog input terminals are available: 17 temperature sensor inputs (thermocouple and platinum resistance thermometer), seven voltage inputs, and two current inputs. You can choose one of these 26 analog inputs in the “analog input 1 type” parameter.
- These terminals are available only on 2-input ES100P. You can choose either of voltage input or current input in parameter settings.
- Terminals are provided on standard ES100P (including heating-cooling models) for CT input for use in heater current detection.
- Terminals are provided on position-proportional ES100P for potentiometer input for use in valve opening measurement.
- Of the ES100P on which auxiliary inputs can be used, up to eight auxiliary input terminals can be used on models provided with expanded I/O connectors, and up to three auxiliary input terminals can be used on models not provided with expanded I/O connectors.
- The application of the auxiliary input terminals can be designated by the digital operation assignment function. Before shipment from the factory, switch inputs for run, reset and advance are assigned to the auxiliary input terminals
- On ES100P provided with expanded I/O connectors, the auxiliary input terminals cannot be used when using BCD communications. BCD communications is switched to in parameter settings.

■ Output

● Control output (analog output)

- Two control output terminals are provided: control output 1 and control output 2. You can choose between relay output, SSR output, voltage output and current output for each of these terminals depending on the type of output unit installed on the main unit.
- In position-proportional control systems, control output 1 is used for open output and control output 2 is used for closed output. So, a relay output unit is used as the output unit. This output unit is already installed in position-proportional controllers before shipment from the factory, so the user need not to obtain a separate output unit.

● Transfer output (current output)

- This terminal is exclusively for current output. Output data can be designated to this terminal by the analog operation assignment function. PV is assigned to this terminal before shipment from the factory.

● Auxiliary output (digital output)

- Ten auxiliary output terminals are provided: auxiliary outputs 1 to 10.
- Auxiliary outputs 1 and 2 are for relay output, and auxiliary outputs 3 to 10 are for open-collector output.
- Auxiliary outputs 3 to 10 sometimes cannot be used depending on the model of ES100P.
- Output data can be designated to auxiliary outputs by the digital operation assignment function. Event output is assigned to auxiliary outputs 1 and 2 before shipment from the factory.
- When using BCD communications on ES100P provided with expanded I/O connectors, auxiliary outputs 3 to 10 cannot be used.



Terminal names and operation assignments

On the ES100P, the functions of I/O terminals are determined by the “operation assignment function.” That is, inputs correspond to arguments, and outputs correspond to assignment destinations. Sometimes, however, the terminal name differs from the name used in operation assignment. The purpose of this is to match the terminology used in conventional temperature controllers and digital controllers. The following table shows the correspondence between terminal names and the name used in operation assignment.

Terminal Name	Argument or Assignment Destination	Terminal Name	Argument or Assignment Destination
Control output 1	Analog output 1	Transfer output	Analog output 3
Control output 2	Analog output 2	Auxiliary input 1	Digital input 1
Auxiliary output 1	Digital output 1	Auxiliary input 2	Digital input 2
Auxiliary output 2	Digital output 2	Auxiliary input 3	Digital input 3

For details on the operation assignment function, see page 1-10.

1.4 Parameters and Setting Levels

The ES100P has two setting levels, setting level 1 and setting level 2. These two setting levels support different parameters.

● Setting level 2

This setting level is for determining the specifications of the controller. Running of programs is stopped when this setting level is entered.

Of the parameters in setting level 2, unit or reference information used in setting level 1 parameters must be set before the related setting level 1 parameter is accessed.

In setting level 2, parameters are distributed among the following setting modes:

- Specification setting mode
- Event setting mode
- ON/OFF timer setting mode
- Digital operation assignment setting mode
- Analog operation assignment setting mode
- Setting level 2 technical mode

● Setting level 1

This setting level is for setting performance or operating conditions.

In setting level 1, parameters are distributed among the following setting modes:

- Manual mode parameter setting mode (available only in the manual mode)
- Operation mode
- Tuning mode
- Program setting mode
- PID set setting mode
- Adjustment mode
- Check mode
- (Setting level 1 technical mode)

Each of these modes except setting level 1 technical mode can be verified by lighting of their respective LEDs.

● Switching between setting levels

To switch between setting levels 1 and 2, you need to change the settings of the DIP switches located inside the main unit of the ES100P.

Setting levels 1 and 2 are each provided with a technical mode to set the technical parameters. You can enable (and disable) access and display of the technical modes by changing the DIP switch settings.

1.5 SP Mode

On the ES100P, you can use one of local SP (LSP), remote SP (RSP) and fixed (FSP) as the set point (SP). Each of these SPs is designated in an “SP mode.”

● Local SP mode

Execution of programs is started in the local SP mode. In the local SP mode, the SP is calculated from the “local SP” parameter set for each of the programmed steps.

When another mode is switched to from the local SP mode during program execution, the SP changes. The program, however, continues to advance as instructed.

● Remote SP mode


In the remote SP mode, the result of analog operations that takes the assignment destination as the “RSP” is used as the SP. This SP is called the “remote SP.”

The remote SP mode is set, for example, when controlling external analog input data (using analog input 2) as the SP.

● Fixed SP mode

In the fixed SP mode, the setting of the “fixed SP” parameter is used as the SP. The fixed SP mode is set when performing control by a fixed value.

The SP change rate can be limited in the remote SP and fixed SP modes.



About setting modes

You can choose between settings made on the front panel, by serial communication and by BCD communications for use in parameter settings. Settings made on the front panel are called “local settings”, serial communications (serial and BCD) settings are called “remote settings”, and BCD communication settings are called “external settings”.

Note that the terms “local” and “remote” differ from “local” and “remote” used in the SP modes. Remember this when setting the SP mode and parameters.

1.6 Operation Assignment Function

■ What is an “operation assignment”?

- ES100P I/O data is used according to the values set to tables. These tables describe how I/O data are is to be handled. Accordingly, you can use I/O data as it is as control data in the same way as on conventional digital controllers. Data can be further manipulated by “operations,” so the optimum I/O functions can be achieved for the control target. This is referred to as the “operation assignment function.”
Tables describing how I/O data is to be handled are called “operation assignment tables.”
- There are two operation assignment functions: the “digital operation assignment function” and “analog operation assignment function.” The function to be used depends on the type of data that is to be handled.
- Moreover, “mixed analog/digital operation” for exchanging data between analog and digital operations also is possible.


● Operation assignment table

- The content of operation assignment tables are described in the “digital/analog operation assignment” parameters.
- Operation assignment tables are made up of “operation blocks” and “assignment destinations.”

Table 1	Table 2	-----	Table n
Assignment Destination	Assignment Destination	-----	Assignment Destination
Operation block	Operation block		Operation block

● About operations

- At the operation block, an operation that is executed using two arguments is handled as the basic unit. Each of these operations is given a No.
- Operations are executed from the smallest operation No. upwards, and end when the program reaches the operation END code.
- The result of each operation is output to the assignment destination.
- Table settings are executed in table No. order.



■ Digital operation assignments

- The digital operation processes external digital inputs, flags for internal ON/OFF timers, events and control status as arguments “1” or “0,” and outputs to assignment destinations such as digital outputs, operating instructions and the digital user buffers.
- The ES100P is provided with 30 operation assignment tables. The settings of assignment destinations in unused tables should be set to “0” (disabled). The results of digital operations can also be used as the arguments for the subsequent operation.
- The operation block is made up of operations 1 to 4. This is shown in the following diagram.

Table 1	Table 2	-----	Table 30
Assignment destination	Assignment destination	-----	Assignment destination
Operations 1 to 4	Operations 1 to 4	-----	Operations 1 to 4


■ Analog operation assignments

- The analog operation process external analog inputs, SP, PV and control operation data as arguments, and assigns the external results of operations to assignment destinations such as control outputs, transfer outputs and the analog user buffers.
- The ES100P is provided with 15 operation assignment tables. The settings of assignment destinations in unused tables should be set to “0” (disabled).
- The operation block is made up of operations 1 to 15. This is shown in the following diagram.

Table 1	Table 2	-----	Table 15
Assignment destination	Assignment destination	-----	Assignment destination
Operations 1 to 15	Operations 1 to 15	-----	Operations 1 to 15

■ Mixed analog/digital operation

- The ES100P is provided with a common data area for sharing the results of digital and analog operations.
- Up to eight sets of data for expressing the states “0” and “1” can be set to this data area.
- In digital operations, this area can be used for arguments or assignment destinations.
- In analog operations, the results of comparing the sizes of arguments are set as data “1” or “0”. Also, arguments can be selected according to the value set to this data.
- Accordingly, you can select either of two sets of analog data using the results of digital operation, and assign the results of comparing the analog data to digital outputs.



1.7 Fine Tuning

Fine tuning is executed in the following cases:

- If you are not satisfied with the control performance of the ES100P after executing A.T. (auto-tuning)
- When PV disturbance or control cancellation caused by A.T. is not allowed in the system


With the fine tuning function, three improvement required levels are set for improvement of control performance. Fuzzy logic inference is executed from the improvement requirements and the control state up to that point to automatically correct PID parameters.

There are three improvement required levels:

- Hunting inhibit required level
- Overshoot inhibit required level
- Response improvement required level

The strength of each of these required levels can be designated in five stages.

If two levels of control are required for a control target, two required levels can be set simultaneously. For example, you can set the required level for the “hunting inhibit” and “overshoot inhibit” parameters if both hunting and overshoot need to be improved. You cannot set three levels of control simultaneously for a control target.



CHAPTER 2

PREPARATIONS

2.1	Installing the ES100P -----	2-2
	Output unit -----	2-2
	External dimensions -----	2-3
	Drilling mounting panels -----	2-3
	Mounting the ES100P -----	2-3
2.2	Setting the Switches -----	2-4
	Switch names -----	2-4
	Switch functions -----	2-4
2.3	Wiring Terminals -----	2-5
	Precautions when wiring -----	2-5
	Input wiring -----	2-5
	Output wiring -----	2-6
	Wiring communication	
	terminals -----	2-7
2.4	Wiring Expanded I/O	
	Connectors -----	2-8
	Connections -----	2-8
	Compatible connectors -----	2-9
	Connecting to I/O	
	terminal block -----	2-9

2.1 Installing the ES100P

■ Output unit


Four types of output unit are available for the ES100P. Select the output unit appropriate for how your ES100P is applied.

● Types of output unit


The following table shows the output units and their ratings.

Unit Type	Model	Rating
Relay Output Unit	E53-R	1c 250 V AC, 5 A (resistive load) Mechanical life: 1,000,000 uses or more Electrical life: 100,000 uses or more
SSR Output Unit	E53-S	1a 75 to 250 V AC, 1 A (resistive load)
Voltage Output Unit	E53-Q E53-Q3 E53-Q4	NPN type 12 V DC, 40 mA NPN type 24 V DC, 20 mA PNP type 24 V DC, 20 mA
Linear Output Unit	E53-C3	4 to 20 mA DC (load 600 Ω or less) Possible for approx. 2600 resolution
	E53-C3D	0 to 20 mA DC (load 600 Ω or less) Possible for approx. 2600 resolution
	E53-V34	0 to 10 VDC (load 1 k Ω or more) Possible for approx. 2600 resolution
	E53-V35	0 to 5 VDC (load 1 k Ω or more) Possible for approx. 2600 resolution

● Mounting the output unit



Pull out the body while pushing in the catch at the bottom of the controller.



Insert the output unit into the on-board socket following the procedure below.



- (1) Pull out the controller body.
Push in the catch at the bottom of the controller to unlock the front panel from the rear panel. Pull out the body with the catch pushed in.
- (2) Mount the output unit.
Insert the output unit for control output 1 into the on-board socket marked "OUTPUT1" and the output unit for control output 2 into the on-board socket marked "OUTPUT2."
- (3) Snap in the attachment clips to hold the output unit firmly in place.



Output unit of position-proportional controllers


With position-proportional controllers (model ES100P-RRP), a relay output unit is provided at purchase. Therefore, this relay output unit does not need to be purchased separately.

External dimensions



CHAPTER 2

Drilling mounting panels




Recommended thickness of mounting panel: 1 to 8 mm

Mounting cutout: 92 mm square

When mounting two or more ES100P, mount the controllers at intervals of at least 100 mm in the horizontal direction and at least 120 mm in the vertical direction.

Securing the ES100P in position




Slot the two fixtures (supplied) into the fixing slot on the rear case with the ES100P pushed into the mounting hole. The fixing slots are located on the top and bottom of the rear case.

Tighten the fixture screw until the ratchet turns idly.

2.2 Setting the Switches

■ Switch names



■ Switch functions

The table below shows the combination of DIP switch settings for achieving the following six functions.

Function	Switch Positions				
	SW1	SW2-1	SW2-2	SW2-3	SW2-4
Setting level 2 Technical mode (enabled)	○	–	○	×	×
Setting level 2 Technical mode (disabled)	○	–	×	×	×
Setting level 1 Technical mode (enabled)	×	○	–	–	–
Setting level 1 Technical mode (disabled)	×	×	–	–	–
Communications test (disabled/enabled)	○	–	–	–	○
Initialization mode	○	–	–	○	×

○ : ON × : OFF – : ON/OFF

- All DIP switches are set to OFF before shipment from the factory.
- The “initialization mode” returns parameter settings to factory defaults.
- Set items marked “–” to the more frequently used switch setting. For example, if both switches SW2-1 and SW2-2 are set to ON, both the setting level 2 and 1 technical modes are enabled just by switching SW1.



● Executing the switch functions

Switch functions excluding the communications test can be executed in the ES/TOOLS Support Software. However, note that when you execute a switch function from the ES/TOOLS Support Software, the switch settings may differ from the function (e.g. setting level) set on the switch.

To execute the function set on the switch as instructed in the switch settings, turn the power supply OFF then back ON again.


● Operation limitations

Note that regular functions such as setting operations and communications do not work when executing the communications test and when in the initialization mode.


2.3 Wiring Terminals

■ Precautions when wiring

- Use ducts to separate input leads and power lines in order to protect the controller and its lines from external noise.
- We recommend using solderless terminals when wiring the controller.
- Tighten the terminal screws using a torque no greater than 78 N/cm (8 kgf/cm). Take care not to tighten the terminal screws too tightly.
- Use solderless terminals applicable to M3.5 screws.




- When using soldered terminals, strip back the tip of the lead about 6 to 12 mm, and solder the tips of the exposed lead wire.




■ Input wiring


● Analog input



- Connect analog input 1 to terminal Nos. 26 to 30. The input type determines how terminals are wired.




- Terminal Nos. 9, 10, 18 and 19 can be used for analog input only on 2-input type ES100P. So, check the model type before wiring inputs. Connect analog input 2 to terminal Nos. 9, 10, 18 and 19. The input type determines how terminals are wired.



- Analog input 2 is insulated from internal circuits.


● CT input
● Potentiometer input




- On position-proportional controllers, connect the potentiometer input to terminal Nos. 31 to 33. On other types of controllers, connect CT input (heater current detection) to these terminals. The functions of these terminals are fixed, and cannot be changed by operation assignment, for example.



● Auxiliary input




- Connect auxiliary inputs 1 to 3 (including COM terminal) to terminal Nos. 20 to 23. Run (DI1), reset (DI2) and hold (DI3) are assigned as switch inputs to these terminals before shipment from the factory. These terminals are enabled only on models ES100P-□□□D.




- Auxiliary inputs are insulated from internal circuits. However, note that auxiliary inputs are not insulated from transfer output and control output when a current or voltage output unit is installed.

■ Output wiring


● Control output




- Connect control outputs 1 to terminal Nos.4 and 5, and control outputs 2 to terminal Nos.13 and 14. Connect the control outputs to suit the output unit mounted on the ES100P. When connecting voltage or current output, check the polarity of the connection before wiring. For details on output units, see page 2-2.




- When carrying out heating-cooling control, use control output 1 as heating output, and control output 2 as cooling output.




● Auxiliary output



- Connect auxiliary outputs 1 to terminal Nos.1 to 3, and auxiliary outputs 2 to terminal Nos.11 and 12. These terminals are assigned as deviation upper limit alarm output before shipment from the factory.




- Terminal Nos. 9, 10, 18 and 19 can be used for auxiliary output only on ES100P-□□□D models. So, check the model type before wiring outputs. Connect auxiliary outputs 3 and 4 to terminal Nos.9 and 10. The +24 V power supply should be connected to terminal Nos.18 and 19. These terminals are assigned as time signals 1 (DO3) and 2 (DO4) before shipment from the factory.




CHAPTER 2

● Transfer outputs




- Connect transfer output to terminal Nos.34 and 35. These terminals are enabled only on models ES100P-□□F□.




- Transfer outputs are insulated from internal circuits. However, note that transfer outputs are not insulated from control output and auxiliary input when a current or voltage output unit is installed.

■ Wiring communication terminals



- Terminal Nos. 15 to 17, 24 and 25 are used for wiring communication terminal. The terminals of models ES100P-□□01□ are arranged for RS-232C communication, and the terminals of models ES100P-□□04□ are arranged for RS-422/485 communication. Check which model communication terminals are to be wired to before wiring.




2.4 Wiring Expanded I/O Connectors

Expanded I/O connectors can be used on models ES100P-□□□□E. Either of the digital I/O terminals or BCD communications terminals can be selected for use in the parameter settings. (The ES100P is set for digital I/O before shipment from the factory.)

The following description assumes that the ES100P has been set for digital I/O. For details on using the ES100P for BCD communications, see the ES100 Digital Controller User's Manual (Communications Guide) (Cat. No. H072-E1-1).

Digital inputs 1 to 8 and digital outputs 3 to 10 are provided for expanded I/O connectors. External 24 V DC power supplies are required for each of digital input and output.

■ Connections



- The following pins are connected to each other internally.
1-2, 3-4, 21-22 and 23-24
- Items in parentheses () indicate the defaults assigned to terminals before shipment from the factory.


■ **Compatible connectors**

Use an OMRON XG4M-3430 connector or equivalent product as the connector for the cable for connecting to the expanded I/O connectors.


■ **Connecting to I/O terminal block**

We recommend the following connection configurations when connecting I/O of the expanded I/O connectors to a terminal block.


● **When connecting output to the I/O relay terminal:**



● **When connecting input to the terminal block and output to the I/O relay terminal:**



● **When connecting both input and output to the terminal block:**



CHAPTER 2

● **Terminal block wiring diagram**

When using one of the above recommended connection configurations, the wiring at the terminal block is as follows.

I/O terminal block (XW2B-34G5)

GNDI	+24 VI	DI1	DI3	DI5	DI7					GND0	+24 V0	DO3	DO5	DO7	DO9		
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31	33	
	2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32	34
	GNDI	+24 VI	DI2	DI4	DI6	DI8					GND0	+24 V0	DO4	DO6	DO8	D10	

Input terminal block (XW2B-20G5)

+24 VI	GNDI	DI1	DI3	DI5	DI7					
1	3	5	7	9	11	13	15	17	19	
	2	4	6	8	10	12	14	16	18	20
	+24 VI	GNDI	DI2	DI4	DI6	DI8				

I/O Relay Terminal (G7TC-OC08)


24 V0		DO3	DO4	DO5	DO6	DO7	DO8	DO9	DO10
+		0	1	2	3	4	5	6	7
-		C0	C1	C2	C3	C4	C5	C6	C7
GND0									

CHAPTER 3

BASIC OPERATION

3.1	Operation Flow -----	3-2
3.2	How to Use the Panel Keys -----	3-3
3.3	Setting I/O Specifications -----	3-4
	Analog input -----	3-4
	Direct/reverse action -----	3-6
	Control output cycle -----	3-6
3.4	Key Display and Assignments ---	3-7
	PF key -----	3-7
	Bar graph -----	3-8
3.5	Setting Events -----	3-9
	What is an “event”? -----	3-9
	Event specifications -----	3-9
	Event settings -----	3-12
3.6	Setting up Programs -----	3-13
	How programs are configured ---	3-13
	Pattern parameters -----	3-14
	Step parameters -----	3-17
	Editing steps -----	3-20
3.7	Starting and Stopping	
	Control -----	3-21
	Starting operation -----	3-21
	Stopping operation -----	3-21
3.8	Adjusting Control Operation -----	3-22
	Changing currently executing	
	patterns -----	3-22
	Manual operation -----	3-23
	Auto-tuning -----	3-24
	Fine tuning -----	3-26

3.1 Operation Flow



Initializing parameters

Follow the procedure below to restore the ES100P parameter settings to the defaults set before shipment from the factory.

- (1) Set switches SW1 and SW2-3 to ON.
- (2) The No.1 display indicates **[L E r]**.
- (3) Press the **[ENT]** key. This executes initialization of the ES100P.
- (4) When the No.1 display indicates **[E n d]** this indicates that initialization has ended.
- (5) Restore the switches to their original positions.